



How it works



Choose your enclosure



Select your interlocked socket



Pick your RCCB device

To install:

1. Attach interlocked socket to the two screws at the bottom of the enclosure
2. The socket will safely rest, leaning forward to expose the wires
3. The installer can now work safely on wiring



Ideal for temporary sites, leisure and OEM applications



Easy to Use

Self compensating screwless earth terminals on the socket outlets make installation hassle free



Universally Compatible

Our range can be used with all EN 60309 Compliant products



Robust

Plugs & sockets are encased in high quality housing for long life and reliable ongoing performance

