

This document must be retained for future reference.

It is the responsibility of the person installing the electrical equipment to ensure that the installation meets the requirements of the IET wiring regulations and is therefore 'fit for purpose'. Factors such as correct selection of components, cable sizing, protective devices and Earth bonding are all critical and should be checked prior to full testing and power-up. Any other regulations applicable to the equipment being installed such as the Machinery Directive and current health and safety legislation must also be adhered to.

All connections (including factory made) must be checked for the correct tightness prior to commissioning of the electrical installation. All connections should also be inspected periodically to ensure correct tightness.

DO NOT USE POWER TOOLS ON THESE PRODUCTS

RRICE Z



RB2-PY9330

Specifications and dimensions

- Legend Plates
- For all 22mm devices



Features	
Type 6	60mm diameter emergency stop legend plate
Related Products	
Other types available Other types available U C SI G M R G H C B H C G M R G H C G B C C C C C C C C C C C C	Start Stop Reverse Up Down On Off Open Close Auto Hand Reset Off-On Start-Stop Up=Down .1 .2 .3 G1-N-G2 Man-Auto (left & right position) Ready trip Gen supply .amp test Auto-hand Hand off auto Change over Black arrow up White arrow down

ALL PRODUCTS, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE.