

This document must be retained for future reference.

It is the responsibility of the person installing the electrical equipment to ensure that the installation meets the requirements of the IET wiring regulations and is therefore 'fit for purpose'. Factors such as correct selection of components, cable sizing, protective devices and Earth bonding are all critical and should be checked prior to full testing and power-up. Any other regulations applicable to the equipment being installed such as the Machinery Directive and current health and safety legislation must also be adhered to.

All connections (including factory made) must be checked for the correct tightness prior to commissioning of the electrical installation. All connections should also be inspected periodically to ensure correct tightness.

DO NOT USE POWER TOOLS ON THESE PRODUCTS



## EUCA11 Auxiliary Switch 1P Changeover

- Suitable for use with either 6kA or 10kA MCB's
- Fits on the left hand side of the MCB
- Max 2 Aux Switches per MCB
- The EUCA11 Auxiliary Switch is compatible only with B and C Curve MCBs. It is not suitable for use with D Curve MCBs



Max operating current		
AC12	400V	3A
	230V	6A
DC12	130V	1A
	48V	2A
	24V	6A

